

## 2013-FORKLIFT TIPPING SKIP



The 2013 fork lift tipping skip is the ideal solution when moving waste around your site or factory. With four way fork pocket entry the units can be placed exactly where required (can also be supplied in a "crane lift" version – ask about the 2013C). Leading the way in health and safety each unit is supplied with a fixed heel pin and "tear-drop" safety catch to ensure the skip doesn't discharge during transit.

Product Code	SWL (kg)	Capacity (Itrs)	Height (mm)	Width (mm)	Length (mm)	Weight (kg)
2013.8	1000	500	1060	1080	1370	220
2013.10	1000	750	1060	1180	1370	230
2013.12	1500	1200	1250	1200	1750	230
2013.14	1500	1500	1250	1560	1820	250

Appearance may vary from picture above.

GPS Lifting Ltd Tel 0161 501 1009  
sales@gpslifting.co.uk www.gpslifting.co.uk

The following instructions must be read and understood by each intended user of this equipment; if there is anything you do not understand contact Eichinger Equipment Ltd.

Ensure the equipment is adequate for the job you need to carry out.

You must not operate this equipment if you are under the influence of alcohol, drugs or if you are feeling unwell.

A risk assessment should be carried out prior to moving or using this equipment.

The following PPE (Personal protective equipment) should be worn when using this equipment:

Gloves / Goggles / Hard Hat / Steel Toecap boots / Hi-Vis Vest

We also suggest suitable clothing should be worn.

### **Familiarise yourself with the equipment, its use and how it works!**

As this equipment is used at multi-level, ensure the intended area for use is clear of overhead cables and power lines or similar hazards which may affect its safe use. This equipment must always be used in conjunction with your site safety policies.

The work area must be clear of obstructions with adequate space for the operative to work safely around the equipment.

Check and ensure the equipment is inspected and in a safe condition prior to its use. Also ensure that its load is stable and secure.

Set the forklift's forks to the appropriate width to suite the tipping skips fork pockets.

Approach the tipping skip with the forklift and line the forks up with the fork pockets. Detach the heel pin / safety chain from the tipping skip and then insert the forks into the fork pockets ensuring the skip is mounted as far back on the forks as possible.

Re attach the heel pin / safety chain ensuring the assembly goes behind the heel of the fork and so securing the unit to the fork lift.

The forklift tipping skip is designed to tip once released and then automatically return to the locked position. For effective operation ensure the skip is loaded evenly. If the majority of the load is at the rear of the skip the tipping mechanism will not operate adequately.

### **THE LEVER SAFETY PLATE SHOULD BE USED AT ALL TIMES WHEN THE SKIP IS NOT BEING EMPTIED.**

Once the tipping skip is landed safely and is in the locked position the operatives may load the skip.

Ensure the load is no bigger than the tipping skip either in dimensions or weight (Under no circumstances should the intended load sit on top of the skip).

Once loaded raise the skip off the ground. The tipping skip should be kept at a low level and should not impede the visibility of the fork lift driver. Now continue to the required emptying point.

Once at the emptying point disengage the lever safety plate and raise the skip enough to ensure that the load can be discharged into the intended area (skip). Pull down the release handle and release it allowing the handle to return to its start position.

Once the skip has automatically returned to its locked position return the lever safety plate over the release lever ready for transit.

